


PART NAMES AND FUNCTIONS

Model NO:HR6CF306




Never touch the interior of the Freezer Chamber or frozen foods in the compartment with wet hands as this could result in frostbite.



The above image is for reference only, configuration is subject to actual product.

TEMPERATURE ADJUSTMENT

- To adjust the temperature inside the freezer compartment, adjust the temperature control dial on front-bottom side of the chest freezer. Normal operation setting is at level 4.
- If the cooling performance is inadequate, turn the temperature control dial in the direction of 7. If too cold, turn dial in direction of 1.
- When you stop running temporarily, please turn the temperature control dial in the direction of 0.



SPECIFICATIONS

Product Name	Chest Freezer		
Product No.	HR6CF306		
Capacity	306L		
Net Dimensions(mm) (excluding handle)	Width	Depth	Height
	1125	672	842
Performance	Freezer compartment temperature: -18°C ; Conditions: Ambient temperature 38°C , unloaded state, not exposed to direct sunlight.		
Net Weight	51kg		



The specifications may change, please refer to the circuit name plate on the back of your chest freezer.